HOMEBASE DIY INSTALLATION



Step 1) Plan your installation.

Nomow artificial grass comes in either 2 metre or 4 metre width rolls. The grass has a directional pile and it is preferable to lay the grass leaning towards the house or seating area. Draw a diagram of your garden and work out your required square meterage and the optimum layout for rolls of grass. Try to minimise the number of joins you will need.

Step 2) Landscaping and ground preparation.

Dig up the current layer of soil using a shovel. Make sure the ground is even and flat. A top layer of sand or sharp sand (30mm deep) can help to make the surface as even as possible. Cover with a layer of Weed Membrane (this will be provided Free of Charge if required). For laying on concrete or tarmac, Weed Membrane won't be needed, but a layer of Shockpad is recommended.





Step 3) Roll out your artificial grass.

Simply roll out your artificial grass like a carpet. Line up the joins neatly and use our self-adhesive joining tape to connect the pieces of artificial grass. The tape will connect the backing of the artificial grass. One roll of the self-adhesive joining tape will connect a 4 metre long join. Alternatively you can use the Nomow Joining Kits or a combination of Adhesive Tubes and Joining Tape.

Step 4) Edges and Finishing.

If your artificial grass exceeds its boundary, fold it back and cut the backing with a sharp knife so that it fits the perimeter neatly. Use our flat head Fixing Pins (Provided Free of Charge) to secure the perimeter of the installation. Once you've finished, brush back the grass with a strong brush. Then sit back, and enjoy. Brush back the grass and enjoy your garden.

