Instructions



1 Turn the screw knob counterclockwise.



2 Unscrew the nut.



3 Insert the blade hole into the screw, as shown in the image.



4 Align the nut with the screw and tighten it clockwise.