



# HOMEBASE

## MADISON BASIN

### INSTRUCTION MANUAL

**IMPORTANT:** Please read these instructions before using the product and retain for future use.

HHGL Limited, MK9 1BA  
HHGL (ROI) Limited, D02 X576

# INSTALLATION

## PRE-INSTALLATION CHECKS

- 1) Check that the basin is compatible with your current layout requirements.
- 2) Before installing the basin, please make sure you have received all items and that they are undamaged. Any damage claims after installation will not be accepted.
- 3) Check that the floor and wall are level and perpendicular.

## INSTALLATION ADVICE

- 1) Water must be turned off at the mains supply before you begin installation. Pipe installation must comply with all local regulations regarding plumbing and other specific requirements.
- 2) Lay the furniture on a soft surface to avoid any damage, such as scuffs or scratches, and inspect as any fault reported after this stage will not be accepted.

## CARE INSTRUCTIONS

- 1) Use a mild detergent, such as liquid soap and warm water for cleaning. Do not use abrasive cleaners that may scratch or dull the surface.
- 2) Carefully read the cleaning product label to ensure the cleaner is safe for use on the material.
- 3) Wipe surface and rinse completely after cleaning application. Rinse and dry any overspray that lands on nearby surfaces.
- 4) Use a soft, dampened sponge or cloth; never use an abrasive material, such as a brush or scourer.
- 5) Maintain good ventilation in the bathroom, keeping the air flowing as much as possible.

## TOOLS REQUIRED (NOT INCLUDED)



Silicone

## INSTALLATION INSTRUCTIONS

Apply a bead of plumber's grade silicone around the top edge of the vanity cabinet. Place the basin in position and align with the vanity cabinet, so there is equal overhang on the left and right side of the vanity cabinet. Allow 24 hours for the silicone to dry before connecting to the water mains and sewage outlet.

