

5 LED METAL SCROLL CANDLE BRIDGE



INSTRUCTION MANUAL

IMPORTANT: Please read these instructions before using the product and retain for future use. HHGL Limited, MK9 1BA; HHGL (ROI) Limited, D02 X576

Product Specification	
Overall Dimensions	H30 x W32 x D5cm
Battery Operated	2 x AA batteries required
Number of LEDs	5

Contents

• 1 x 5 LED metal scroll candle bridge

Caution

- Do not leave used batteries for long periods in the battery compartment.
- Do not mix old and new battery types, replace all batteries at the same time.
- Remove batteries if the candle bridge is unlikely to be used for extended periods.

Lights

 The LEDs are a non-replaceable LED type, but have been manufactured to last for a long time.

General handling and installation

- Handle candle bridge with care, do not allow heavy contact with hard surfaces.
- Candle bridge should be kept out of reach of small children and pets.

To operate

Use the slide switch at the bottom of the candle bridge to turn the candle bridge ON or OFF.

Battery replacement

- 1. When the candles becomes dim, the batteries need replacing.
- 2. Open the battery compartment by sliding off the cover.
- Replace all the batteries with new AA size batteries (Alkaline recommended).
- Observe the correct polarities as marked when replacing the batteries.
- 5. Refit the cover.

