A5 148mm x 210 mm GBIN005279-2

# **HOMEBASE**

# **6 WHITE LED TEA LIGHTS**

Product Specification	
Overall Dimensions	H3.8 x Dia. 4.2cm
Battery Operated	1 x CR2032 battery required per tea light
Light	Warm white LEDs

#### Contents

- · 6 x LED tea light candles
- 6 x CR2032 batteries

#### General handling and installation

- Handle the tea lights with care; do not allow heavy contact with hard surfaces.
- Ensure the tea lights are not positioned where they can be inadvertently damaged by doors, moving objects, people or animals.
- These are not a toy. Keep the light and batteries out of reach of small children and pets.
- For indoor use only.

### To operate

Use the slide switch at the bottom of the light to turn the light set ON or OFF.

#### Battery replacement

- When the light becomes dim, the battery needs replacing.
- 2. Remove the retaining screw and open the battery cover.
- Replace the drained battery with new CR2032 Lithium coin batteries.
- Observe the correct polarities as marked when replacing the battery; positive terminal is facing up.
- Fit the battery cover and tighten the screw to secure it
- 6. Dispose of the drained batteries properly.
- 7. Batteries shall be replaced by adults only.

#### User tips

- Do not leave used batteries for long periods in the battery compartment.
- Remove the batteries if the light is unlikely to be used for extended periods. Keep the batteries in a safe place.



CAUTION Lithium Cell Battery inside (CR2032 TYPE)

### SAFETY WARNING

This product contains a LITHIUM COIN type battery.

WARNING! Please ensure the coin battery is kept OUT OF REACH OF CHILDREN.

kept OUT OF REACH OF CHILDREN. The battery presents a significant choking and burn hazard to young children, should they swallow a battery.

Children under the age of 4 are especially prone to accidental swallowing of objects such as these.

If a lithium coin battery is swallowed, SEEK IMMEDIATE MEDICAL ATTENTION.

Do not let the child eat or drink; Do not induce vomiting.

To keep your children safe:

- Keep devices that use coin batteries out of reach of small children
   Keep new batteries in their packaging until ready to use and store in places out of reach of children
- Safely dispose of spent batteries immediately
- Share this information with your family, friends, caregivers and babysitters.

We have designed the coin battery holder to require dexterity, normally beyond that of a small child to access, but nevertheless you should always follow the advice given above. Examine devices and make sure the battery compartment is correctly secured — do not use if compartment is not secure.



The packaging material is recyclable. Dispose of the packaging in an environmentally safe manner and make it available for the recyclable material collection service.





Dispose of the product in an environmentally safe manner when you decide to part with it. This device should not be disposed of with household waste. Dispose of it at a recycling centre, check with your local authority or store for recycling advice. Please note that all products with this symbol must be recycled.



## INSTRUCTION MANUAL

IMPORTANT: Please read these instructions before using the product and retain for future use.

HHGL Limited, MK9 1BA; HHGL (ROI) Limited, D02 X576