

**HOMEBASE**

# SNOWING MUSICAL TABLETOP LANTERN



## INSTRUCTION MANUAL

IMPORTANT: Please read these instructions before using the product and retain for future use.  
HHGL Limited, MK9 1BA; HHGL (ROI) Limited, D02 X576

### Product specification

- Rated input: IP20 4.5V DC 6W
- Bulb rating: 3V 0.03W
- Product dimensions: H67 x W27 x D27cm
- Transformer: JT-DC4.5V6W-E3

### Caution

- Please read these instructions carefully. Keep these instructions in a safe place for future reference.
- For INDOOR use only.
- Do not connect the product to the power supply whilst the product is still in the packaging.
- Unplug when not in use. Always unplug from the mains supply whilst installing, carrying out maintenance or adjustment.
- The lights are constructed with non-replaceable LED bulbs. DO NOT attempt to replace any of the bulbs.
- It is normal for the transformer to run a little warm. Please ensure it's used in a well ventilated area.
- Keep away from sources of heat and naked flames.
- Unplug when not in use.
- When storing away, make sure the area is dry. Avoid any damp, wet and humid areas.
- Use only with the supplied power transformer.

### Operating instructions

1. Unpack the product from the box.
2. Connect the power transformer to the product, then plug the transformer into the mains socket.
3. Switch the power switch to your desired mode:
  - ON 1 will operate lights, rotate and play music.
  - ON 2 will operate lights and rotate without music.
4. Switch it OFF when not in use.

### Disposal and recycling



Electrical products are labelled with the wheelie bin symbol to indicate that they are to be collected and recycled at end of life. Users of electrical products should not dispose of them as unsorted municipal waste but use the separate collection facilities available. Check with your local authority for recycling advice. Customer participation is encouraged to minimise any potential effects on the environment and human health from the potential presence of hazardous substances.