

HOMEBASE

LIGHT UP NEON TREE



INSTRUCTION MANUAL

IMPORTANT: Please read these instructions before using the product and retain for future use.
HHGL Limited, MK9 1BA; HHGL (ROI) Limited, D02 X576

Caution

- For INDOOR use only.
- Do not switch on whilst the product is still in the packaging.
- Requires 3 x 1.5V AA batteries (not included).
- For use as a decoration item, not a toy. Keep out of reach of children and pets.
- **WARNING:** Batteries should only be replaced by an adult.
- Batteries are to be inserted with the correct polarity.
- Do not mix old and new batteries.
- Do not mix different types of batteries, only batteries of the same or equivalent type are recommended.
- Remove the batteries during long periods of non-usage.
- Always remove exhausted batteries from the product. Battery leakage and corrosion can damage the product.
- Dispose of batteries safely. Do not dispose of batteries in a fire. The batteries may explode or leak. Use collection points where available.
- Never short circuit the battery terminals.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Keep away from sources of heat and naked flames.
- This light is constructed with non-replaceable LED bulbs. DO NOT attempt to replace any of the LED bulbs in the light.
- Remove batteries before storing.
- When storing away, make sure the area is dry. Avoid any damp, wet and humid areas.
- Please read these instructions carefully. Keep these instructions in a safe place for future reference.

Operating instructions

1. Unpack the product from the box.
2. Insert the tree part into the hole of the battery box and push down into position (see Fig. A).
3. Open the battery box and insert the required batteries. Please ensure the battery polarity is connected correctly.
4. Close the battery box and secure.
5. Press the switch on the battery box to switch ON the light.
6. Switch it OFF when not in use.




Fig. A

Disposal and recycling



Electrical products are labelled with the wheeled bin symbol to indicate that they are to be collected and recycled at end of life. Users of electrical products should not dispose of them as unsorted municipal waste but use the separate collection facilities available. Check with your local authority for recycling advice. Customer participation is encouraged to minimise any potential effects on the environment and human health from the potential presence of hazardous substances.