


4. TO REMOVE THE SEAT, PRESS THE QUICK RELEASE BUTTON ONCE AND LIFT THE SEAT OFF THE MOUNTING PINS SIMULTANEOUSLY IN THE UPRIGHT POSITION.

5. TIGHTEN BOLTS FULLY. (DO NOT USE A POWER TOOL OR OVER TIGHTEN).



6. ENSURE THE COVERS HAVE BEEN PLACED IN POSITION BEFORE REFITTING THE SEAT.

7. POSITION THE SEAT BACK ONTO THE PINS AND GENTLY PUSH DOWN UNTIL THE SEAT LOCATES ON THE MOUNTING PINS.

8. CHECK THE RELEASE MECHANISM BY REPEATING STEP 4.

