homebase E D I T

BATTERY REPLACEMENT

The battery should typically be replaced annually, or when the charging ability decreases.

To replace the battery, remove the locking screw and open the box (see 'STEP 1').

After taking out the old battery, insert a new 1 x AA 1.2V Ni-MH 600mAh rechargeable battery (see 'STEP 2').

The discarded battery should be disposed of safely. Please recycle where facilities exist.

Check with your local authority or retailer for recycling advice.

STEP 1



STEP 2





HHGL Limited, MK9 1BA; HHGL (ROI) Limited, D02 X576