HOMEBASE E D I T

50 SOLAR MULTICOLOURED BERRY LIGHTS

OPERATING INSTRUCTIONS

- There are 8 lighting modes to choose from. Please select the relevant number on the remote to choose your desired lighting mode.
- Includes remote control with 4.5 metre operating range.
- 1x CR2025 lithium battery included
- Please remove the battery tab before using.

MODE	FUNCTIONS
1	Combination
2	In waves
3	Sequential
4	Slow glow
5	Chasing/Flash
6	Slow fade
7	Twinkle/Flash
8	Steady on



BATTERY REPLACEMENT

The battery should typically be replaced annually, or when the charging ability decreases.

To replace the battery, remove the locking screw and open the box (see 'STEP 1').

After taking out the old battery, insert a new 1 x AA 1.2V Ni-MH 300mAh rechargeable battery (see 'STEP 2').

The discarded battery should be disposed of safely. Please recycle where facilities exist.

Check with your local authority or retailer for recycling advice.



STEP 1



STEP 2

