

AMALA

Installation & Registration Guide

Installation & User Guide



Scan the QR Code or go to the link below:

Installation & User Guide
tritonshowers.co.uk/amalaguide

Or simply email or telephone for your guide:

Email: serviceenquiries@tritonshowers.co.uk
TEL: 024 7637 8327



TRITON

See you first thing Britain

AMALA

Installation & Registration Guide

Installation & User Guide



Scan the QR Code or go to the link below:

Installation & User Guide
tritonshowers.co.uk/amalaguide

Or simply email or telephone for your guide:

Email: serviceenquiries@tritonshowers.co.uk
TEL: 024 7637 8327



TRITON

See you first thing Britain

Register now for your
**FREE FULL
Parts and Labour
GUARANTEE**
REGISTER ONLINE TO
WIN £100
OF LOVE2SHOP VOUCHERS
IN OUR PRIZE DRAW
VISIT OUR WEBSITE
TRITONSHOWERS.CO.UK/REGISTER

Or scan the QR Code

Product registration is only available to units purchased & installed in the UK



ALTERNATIVELY REGISTER BY TEL:
024 7637 8321

FOR YOUR SERVICE REFERENCE

NOTE DOWN THE PRODUCT CODE BELOW
(FROM THE FRONT OR TOP OF THE BOX)

UK registered design No's: 6133977 / 6133978 / 6133979

Register now for your
**FREE FULL
Parts and Labour
GUARANTEE**
REGISTER ONLINE TO
WIN £100
OF LOVE2SHOP VOUCHERS
IN OUR PRIZE DRAW
VISIT OUR WEBSITE
TRITONSHOWERS.CO.UK/REGISTER

Or scan the QR Code

Product registration is only available to units purchased & installed in the UK



ALTERNATIVELY REGISTER BY TEL:
024 7637 8321

FOR YOUR SERVICE REFERENCE

NOTE DOWN THE PRODUCT CODE BELOW
(FROM THE FRONT OR TOP OF THE BOX)

UK registered design No's: 6133977 / 6133978 / 6133979

AMALA

Installation & Registration Guide

Installation & User Guide



Scan the QR Code or go to the link below:

Installation & User Guide
tritonshowers.co.uk/amalaguide

Or simply email or telephone for your guide:

Email: serviceenquiries@tritonshowers.co.uk
TEL: 024 7637 8327



TRITON

See you first thing Britain

AMALA

Installation & Registration Guide

Installation & User Guide



Scan the QR Code or go to the link below:

Installation & User Guide
tritonshowers.co.uk/amalaguide

Or simply email or telephone for your guide:

Email: serviceenquiries@tritonshowers.co.uk
TEL: 024 7637 8327



TRITON

See you first thing Britain

Register now for your
**FREE FULL
Parts and Labour
GUARANTEE**
REGISTER ONLINE TO
WIN £100
OF LOVE2SHOP VOUCHERS
IN OUR PRIZE DRAW
VISIT OUR WEBSITE
TRITONSHOWERS.CO.UK/REGISTER

Or scan the QR Code

Product registration is only available to units purchased & installed in the UK



ALTERNATIVELY REGISTER BY TEL:
024 7637 8321

FOR YOUR SERVICE REFERENCE

NOTE DOWN THE PRODUCT CODE BELOW
(FROM THE FRONT OR TOP OF THE BOX)

UK registered design No's: 6133977 / 6133978 / 6133979

Register now for your
**FREE FULL
Parts and Labour
GUARANTEE**
REGISTER ONLINE TO
WIN £100
OF LOVE2SHOP VOUCHERS
IN OUR PRIZE DRAW
VISIT OUR WEBSITE
TRITONSHOWERS.CO.UK/REGISTER

Or scan the QR Code

Product registration is only available to units purchased & installed in the UK



ALTERNATIVELY REGISTER BY TEL:
024 7637 8321

FOR YOUR SERVICE REFERENCE

NOTE DOWN THE PRODUCT CODE BELOW
(FROM THE FRONT OR TOP OF THE BOX)

UK registered design No's: 6133977 / 6133978 / 6133979

IMPORTANT SAFETY INFORMATION PLEASE READ



Products manufactured by Triton are safe and without risk provided they are installed, used and maintained in good working order in accordance with our instructions and recommendations.

- ▲ **WARNING: DO NOT** operate shower if frozen, or suspected of being frozen. It must thaw out before using.
- ▲ **DO NOT** operate the unit if the shower head or spray hose becomes damaged.
- ▲ **DO NOT** restrict flow out of shower by placing shower head in direct contact with your body.
- ▲ **DO NOT** operate the shower if water ceases to flow during use or if water has entered inside the unit because of an incorrectly fitted cover.
- ▲ **WARNING: If restarting the shower immediately after stopping, be aware that a slug of hot water will be expelled for the first few seconds.**
- ▲ The shower head must be descaled regularly.
- ▲ Fit only shower heads recommended by the manufacturer and never fit any additional device to restrict the water outlet flow.
- ▲ The outlet must not be connected to any tap or fitting other than those specified.
- ▲ This appliance is intended to be permanently connected to the water mains and not connected by a hose set.
- ▲ A suitable double pole isolation switch for supply disconnections must be incorporated in the fixed wiring circuit in accordance with current wiring rules. See Electrical Installation section for further details.

Mains water pressure only.
 Minimum inlet pressure 100kPa (1 bar)
 Maximum inlet pressure 1000kPa (10 bar)

The online book contains all the necessary fitting and operating instructions for your electric shower. Care taken during the installation will provide a long, trouble-free life from your shower.

WARNING

This appliance can be used by children aged from 3 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children may not play with the appliance. Cleaning and user maintenance shall not be made by children.

How can you help us save the environment?

By registering and using our installation & user guides online, you are contributing to saving approximately 25 tonnes of paper annually, equivalent to over 500 trees per year.



IMPORTANT SAFETY INFORMATION PLEASE READ



Products manufactured by Triton are safe and without risk provided they are installed, used and maintained in good working order in accordance with our instructions and recommendations.

- ▲ **WARNING: DO NOT** operate shower if frozen, or suspected of being frozen. It must thaw out before using.
- ▲ **DO NOT** operate the unit if the shower head or spray hose becomes damaged.
- ▲ **DO NOT** restrict flow out of shower by placing shower head in direct contact with your body.
- ▲ **DO NOT** operate the shower if water ceases to flow during use or if water has entered inside the unit because of an incorrectly fitted cover.
- ▲ **WARNING: If restarting the shower immediately after stopping, be aware that a slug of hot water will be expelled for the first few seconds.**
- ▲ The shower head must be descaled regularly.
- ▲ Fit only shower heads recommended by the manufacturer and never fit any additional device to restrict the water outlet flow.
- ▲ The outlet must not be connected to any tap or fitting other than those specified.
- ▲ This appliance is intended to be permanently connected to the water mains and not connected by a hose set.
- ▲ A suitable double pole isolation switch for supply disconnections must be incorporated in the fixed wiring circuit in accordance with current wiring rules. See Electrical Installation section for further details.

Mains water pressure only.
 Minimum inlet pressure 100kPa (1 bar)
 Maximum inlet pressure 1000kPa (10 bar)

The online book contains all the necessary fitting and operating instructions for your electric shower. Care taken during the installation will provide a long, trouble-free life from your shower.

WARNING

This appliance can be used by children aged from 3 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children may not play with the appliance. Cleaning and user maintenance shall not be made by children.

How can you help us save the environment?

By registering and using our installation & user guides online, you are contributing to saving approximately 25 tonnes of paper annually, equivalent to over 500 trees per year.



IMPORTANT SAFETY INFORMATION PLEASE READ



Products manufactured by Triton are safe and without risk provided they are installed, used and maintained in good working order in accordance with our instructions and recommendations.

- ▲ **WARNING: DO NOT** operate shower if frozen, or suspected of being frozen. It must thaw out before using.
- ▲ **DO NOT** operate the unit if the shower head or spray hose becomes damaged.
- ▲ **DO NOT** restrict flow out of shower by placing shower head in direct contact with your body.
- ▲ **DO NOT** operate the shower if water ceases to flow during use or if water has entered inside the unit because of an incorrectly fitted cover.
- ▲ **WARNING: If restarting the shower immediately after stopping, be aware that a slug of hot water will be expelled for the first few seconds.**
- ▲ The shower head must be descaled regularly.
- ▲ Fit only shower heads recommended by the manufacturer and never fit any additional device to restrict the water outlet flow.
- ▲ The outlet must not be connected to any tap or fitting other than those specified.
- ▲ This appliance is intended to be permanently connected to the water mains and not connected by a hose set.
- ▲ A suitable double pole isolation switch for supply disconnections must be incorporated in the fixed wiring circuit in accordance with current wiring rules. See Electrical Installation section for further details.

Mains water pressure only.
 Minimum inlet pressure 100kPa (1 bar)
 Maximum inlet pressure 1000kPa (10 bar)

The online book contains all the necessary fitting and operating instructions for your electric shower. Care taken during the installation will provide a long, trouble-free life from your shower.

WARNING

This appliance can be used by children aged from 3 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children may not play with the appliance. Cleaning and user maintenance shall not be made by children.

How can you help us save the environment?

By registering and using our installation & user guides online, you are contributing to saving approximately 25 tonnes of paper annually, equivalent to over 500 trees per year.



IMPORTANT SAFETY INFORMATION PLEASE READ



Products manufactured by Triton are safe and without risk provided they are installed, used and maintained in good working order in accordance with our instructions and recommendations.

- ▲ **WARNING: DO NOT** operate shower if frozen, or suspected of being frozen. It must thaw out before using.
- ▲ **DO NOT** operate the unit if the shower head or spray hose becomes damaged.
- ▲ **DO NOT** restrict flow out of shower by placing shower head in direct contact with your body.
- ▲ **DO NOT** operate the shower if water ceases to flow during use or if water has entered inside the unit because of an incorrectly fitted cover.
- ▲ **WARNING: If restarting the shower immediately after stopping, be aware that a slug of hot water will be expelled for the first few seconds.**
- ▲ The shower head must be descaled regularly.
- ▲ Fit only shower heads recommended by the manufacturer and never fit any additional device to restrict the water outlet flow.
- ▲ The outlet must not be connected to any tap or fitting other than those specified.
- ▲ This appliance is intended to be permanently connected to the water mains and not connected by a hose set.
- ▲ A suitable double pole isolation switch for supply disconnections must be incorporated in the fixed wiring circuit in accordance with current wiring rules. See Electrical Installation section for further details.

Mains water pressure only.
 Minimum inlet pressure 100kPa (1 bar)
 Maximum inlet pressure 1000kPa (10 bar)

The online book contains all the necessary fitting and operating instructions for your electric shower. Care taken during the installation will provide a long, trouble-free life from your shower.

WARNING

This appliance can be used by children aged from 3 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children may not play with the appliance. Cleaning and user maintenance shall not be made by children.

How can you help us save the environment?

By registering and using our installation & user guides online, you are contributing to saving approximately 25 tonnes of paper annually, equivalent to over 500 trees per year.

