


HOMEBASE

HEXAGONAL POP-UP GAZEBO

INSTRUCTION MANUAL



IMPORTANT: Please read these instructions before using the product and retain for future use.

HHGL Limited, MK9 1BA
HHGL (ROI) Limited, D02 X576

V1_2023

WARNINGS :

- Any assembly or maintenance of the product must be carried out by adults only. We recommend at least 4 adults.
- Do not assemble the gazebo on sandy, muddy or loose soil, as stakes do not have enough anchorage in these types of soil.
- Please check your state and local regulations prior to purchasing. Some jurisdictions may require permits for installation and use. Some special procedures may be valid in your area.
- Install the gazebo on level ground. Stakes are provided to secure the gazebo to the ground.
- If you wish to secure the gazebo to a wood deck or concrete surface, use anchors suited to these surfaces (anchors not included).
- Some parts may contain sharp edges. Wearing protective gloves is advised.
- Keep children and pets away while setting up the gazebo.
- Check all nuts and bolts periodically to ensure they are tightened.
- Do not light any fires under or near the product!
- Snow must be cleared off regularly during snowy days. Remove the snow at the roof top when it is thicker than 2 inches. In order to avoid damage, use a plastic snow rake to remove excessive snow and ice buildup from roof and removal of fallen debris.
- This gazebo is intended for decorative and sunshade purposes only, and it is not designed to withstand harsh weather, including high winds, rain, and snow.
- It is recommended that the canopy be removed in the winter and during high winds.
- If scratched, please use touch up paint to prevent rusting.

MAINTENANCE :


- Steel components for this gazebo are treated with rust inhibiting paint. However, due to the nature of steel, surface oxidation (rusting) will occur if these protective coatings are scratched. This is not a defect and thus not covered by the warranty.
- To minimize this condition, it is recommended to use care when assembling and handling the product to prevent scratching the paint. Should any scratching or damage occur, it is recommended to cover the scratch immediately with rust inhibiting paint (not included).
- Surface rust can also be easily removed with a very light application of regular cooking oil or WD-40. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping onto deck or patio and caused damaging stains, which may be difficult to remove. This can be prevented if the above-mentioned measures are taken to keep the product from oxidizing.
- After a period of use, rinse the ash on top of the gazebo using water. Avoid using acid or alkali wash lotion.
- Do not use bleach, acid, or other abrasive cleaners on the roof or frame parts.
- Do not use a pressure washer.
- Keep instruction manual for future reference.
- Keep the original packaging to store the gazebo.
- Periodically check and ensure that all bolts are well-tighten during use.
- If the product will not be used for a long period of time (e.g. winter time), it should be disassembled and stored in a clean, dry environment.

ASSEMBLY INSTRUCTIONS



Please check you have all the components and fittings listed. If you find any missing or damaged parts, please contact our customer services team on 0333 003 7084 between 09:00 & 18:00, or use the contact form on our website.

www.homebase.co.uk





Parts:

Label	Part Number	Description	Part Image	Qty
A	P005900004	Gazebo Frame		X1
B	P001100428	Canopy		X1
C	P001200167	Mosquito Netting		X1



Fittings:

Label	Part Number	Description	Part Image	Qty
AA	H070010018	Stake D3*145		X12
BB	H070010021	Stake D4*180		X6
CC	H990070004	Rope		X6
DD	P007600069	Bag		X1


Step 1







Step 2



Step 3





Step 4






Match the panel zippers by number as shown in the illustration.

Step 5



Step 6



ATTENTION:

To avoid damage, disassemble the gazebo during bad weather, e.g. during high wind or heavy rain. This product is intended to be used as a temporary shelter and is not designed to be a permanent structure.

