

# HOMEBASE

## 4ft BLUE SPRUCE ARTIFICIAL TREE



### INSTRUCTION MANUAL

**IMPORTANT!** Please read these instructions before using the product. Retain instructions for future use.

HHGL Limited, MK9 1BA; HHGL (ROI) Limited, D02 X576


## Caution

- For indoor use only
- Do not switch on whilst the product is still in the packaging.
- Requires 4 x 1.5V AA batteries (not included).
- For use as a decoration item, not a toy. Keep out of reach of children and pets.
- **WARNING:** Batteries should only be replaced by an adult.
- Batteries are to be inserted with the correct polarity.
- Do not mix old and new batteries.
- Do not mix different types of batteries, only batteries of the same or equivalent type are recommended.
- Remove the batteries during long periods of non-usage.
- Always remove exhausted batteries from the product. Battery leakage and corrosion can damage the product.
- Dispose of batteries safely. Do not dispose of batteries in a fire. The batteries may explode or leak. Use collection points where available.
- Never short circuit the battery terminals.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Keep away from sources of heat and naked flames.
- This light set is constructed with non-replaceable LED bulbs. **DO NOT** attempt to replace any of the LED bulbs in the light set.
- Remove batteries before storing.
- Do not position or place the tree near fire, candles or any other direct sources of heat. Avoid using in damp, wet and humid areas.
- Do not position your tree where it is a hazard to the elderly, children or pets. Take particular care with electric cables.
- Place on a level, hard and flat surface. Do not place where tree is likely to wobble due to an uneven surface, floors or thick carpeting.
- Ensure tree sections are stable and securely attached to the top of your tree.
- Please check all fittings and re-tighten on a weekly basis, or as necessary.
- Save the packaging to store your tree.
- When you have finished using the tree, carefully re-pack following the instructions to ensure the tree remains in a good condition to be re-used. Make sure the storage area is dry, avoid any damp, wet and humid areas.
- Please read these instructions carefully. Keep these instructions in a safe place for future reference.


## Before you start

1. Please check that all parts are present before you start the assembly of your product, as once assembled, this product is exempt from our money back guarantee. This does not affect your statutory rights.
2. For ease and speed of assembly, we recommend that before you commence each step, you identify all the parts required for that step.
3. For larger items, please ensure that you have sufficient space and people to assemble your product safely.
4. We recommend that, where possible, all items are assembled near to the flat area in which they will be placed in use, to avoid moving the product unnecessarily, once assembled. Never allow any part of the set to come into contact with a source of heat or flames.
5. Please keep plastic bags out of reach of children and animals.
6. Locate your tree on a level surface that will not be damaged by the tree.
7. During assembly please take care not to over-tighten any fittings, as this may damage the product.

## Assembled dimensions



## Parts list



No.	Parts List	Qty
1.	Top tree section	1
2.	Bottom tree section	1
3.	Pot	1


## Assembly

### Step 1



Unbox the contents in your desired location. Take out the pot (3) and place it on a flat surface.

### Step 2



Insert the bottom tree section (2) into the pot (3). Then insert the top tree section (1).

### Step 3



### Assembly complete

To shape your tree, pull down the tree tips and adjust the branches to fill any gaps.

## Operating instructions

1. Open the battery box and insert the required batteries. Please ensure the battery polarity is connected correctly.
2. Close the battery box and secure.
3. Press the button on the battery box to switch ON the light set.
4. The light set has a built-in timer function. It will stay on for 6 hours then automatically turn off.  
The timer will set based on the time you first switch the light set ON.  
To reset the timer, switch OFF the light set and switch it back ON at the desired time.
5. Switch it OFF when not in use.

## Care and use

Before using or re-using the tree inspect the product carefully. If there are any damaged parts or exposed sharp points, please dispose of the tree.

## Disassembly and storage

1. Disassemble the tree from the top to the bottom.  
Start with the 'tree top' and gently lift straight up to remove it from the section below, then fold all branches toward the pole.
2. In case of difficulty separating the tree pole (trunk), apply a small amount of lubricant at the joint and rotate the upper pole in both directions. Lift the upper pole up again.
3. Continue by gently lifting each section(s) straight up from the section below and fold all branches toward the pole, until the bottom section is removed from the tree stand.
4. Carefully place all tree sections into the box and tape it shut.
5. When not in use, please store your tree in a cool, dry place away from sunlight. Exposing your tree to excessive heat or humidity may damage your tree.

## Disposal and recycling



Electrical products are labeled with the wheeled bin symbol to indicate that they are to be collected and recycled at end of life. Users of electrical products should not dispose of them as unsorted municipal waste but use the separate collection facilities available. Check with your local authority for recycling advice. Customer participation is encouraged to minimise any potential effects on the environment and human health from the potential presence of hazardous substances.

