


HOMEBASE

COSMO VELVET 2 SEATER SOFA

H93.5 x W144 x D84cm




INSTRUCTION MANUAL

IMPORTANT: Please read these instructions before using the product and retain for future use.

HHGL Limited, MK9 1BA; HHGL (ROI) Limited, D02 X576

ASSEMBLY INSTRUCTIONS

PLEASE CHECK THAT YOU HAVE ALL THE PARTS LISTED BEFORE YOU START ASSEMBLY. IF YOU DO FIND THAT SOMETHING IS MISSING, DO NOT CONTINUE ASSEMBLY. PLEASE CONTACT YOUR LOCAL STORE.



Parts:


No.	Description	Qty
1	Sofa back	x1
2	Sofa base	x1
3	Sofa right arm	x1
4	Sofa left arm	x1
5	Sofa seat cushions	x2
6	Sofa back cushions	x2
7	Sofa legs	x4

Fittings:


No.	Description	Qty
A	Washers 	x4

Place the sofa back (1) side up on a clean and stable surface.
 Screw on sofa legs (7) with washers (A), as illustrated in step 1.
 Place the sofa base (2) bottom-side up on a clean and stable surface.
 Screw on sofa legs (7) with washers (A), as illustrated in step 2.
 Attach the sofa back (1) onto the sofa base (2), as illustrated in step 3.
 Attach the sofa arms (3 & 4) onto the sofa back (1) and the sofa base (2), as illustrated in step 4.
 Finally, put the sofa seat cushions (5) and back cushions (6) on the sofa base (2), as illustrated in step 5.


Step 1




Step 2




Step 3




Step 4



Step 5



THE USE OF POWER TOOLS TO ASSEMBLE THIS PRODUCT WILL INVALIDATE ANY WARRANTY, AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.



General care for velvet:

Over time, velvet can become crushed and change in appearance slightly; however, there are some simple measures you can take to preserve its softness and alluring appeal.

For velvet furniture items that are facing heavy use, it's advisable to gently vacuum the fabric with an upholstery attachment at least once a week. Alternatively, you can also use a soft-bristled brush or clothes brush, ensuring to brush in the direction of the nap of the fabric.

Velvet is prone to marking, so be mindful not to leave anything heavy resting on your furniture for too long, as this can cause marks and dents. Should this happen, pressure marks can be easily removed through light steaming and brushing the affected area.

To help prevent wrinkles, especially on sofas or armchairs where cushions and covers cannot be removed, it's worth turning and shaking them regularly. This will help to avoid any long-term creases which may be more difficult to remove.