



D'LUCCI

USER GUIDE

SENSOR SWITCH SHOWER ROUND


Important

Prior to installation, all parts and components should be thoroughly inspected for defects. This product will not be warranted if it has been installed with pre-existing defects.

Installation


Screw the shower head onto a shower arm. Ensure that the rubber washer is seated correctly.

Usage



Gesture Control

Wave across the sensor to change the spray pattern.



Adjustable Sensor Angle

Change the detection point to suit your requirements.

Care and Maintenance

- Clean with a soft cloth and warm soapy water.
- Do not use harsh detergents, corrosive chemicals, or abrasive cleaners.

Please retain these instructions for future reference.