

**GB: IMPORTANT INFORMATION!**

Please read the entire manual carefully before starting to assemble and/or using this product. Follow the manual thoroughly and keep it for further reference.

**GB: IMPORTANT!**

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.



**GB** Not suitable for children under 3 years due to their inability to use the trampoline.

**GB IMPORTANT INFORMATION.**


The trampoline and net should be packed away during the winter. Make sure that all parts are dry and packed safely. Store in a dry place. Please be aware that wind and weather may cause deterioration.

Please read all the safety instructions and the whole assembly guide before use, and retain for future reference.

We recommend that two people carry out the assembly of the trampoline. Trampoline shall be assembled by an adult in accordance with the assembly instructions and thereafter checked before first use.

Should you want to move the trampoline, a minimum of two people is required. Lift the trampoline carefully, hold it horizontally and pull the trampoline to the required location. If the trampoline is to be moved far, it should be dismantled and reassembled to make sure that it is not damaged.

If the trampoline is not in use for an extended period, it should be dismantled and packed away. Store in a dry place.

**Follow the assembly guide carefully.** **Safety instructions**

This trampoline is for domestic use and may only be used outdoors.

Max load 90 KGS.

The owner or person supervising is responsible for ensuring that all users are sufficiently informed about all safety instructions and correct use of the trampoline!

- Do not use the trampoline without adult, expert supervision.
- No more than one person should use the trampoline at a time. The trampoline is only designed for one person!
- Two people may never use the trampoline at the same time! This increases the risk of injury, including serious injuries such as a broken neck, paralysis, etc.
- Do not perform somersaults! Somersaults increase the risk of landing on your head or neck which may result in serious injuries or even death.
- Limit the time of continuous usage (make regular stops).
- Jump in the middle of the trampoline mat. Hitting the padded edge of the trampoline may cause injuries as this is not designed to be jumped or stepped on.
- Always be careful when climbing onto the trampoline to avoid getting caught in the springs or hitting the frame.
- Always make sure that the padded edge is fitted correctly and covers the frame and springs to avoid injury. Do not jump down off the trampoline. Climb off carefully to avoid injury.
- All users should be aware of their own limitations. The risk of severe injury must be taken seriously. It is important to bend your knees on landing to achieve the best possible control. Jump up and and in the same spot -this provides the best control. Aim

for the middle marking. Gain full control of your jumps before attempting more difficult jumps.

• Do not use the trampoline when you are under the influence of alcohol, medicine or other drugs. This dramatically increases the risk of injury as coordination, judgement and reaction time are affected.

• Do not smoke when using the trampoline.

• Do not use the trampoline if you suffer from high blood pressure.

• Do not use the trampoline if you are pregnant.

• Never jump down onto the trampoline from a roof or other elevations. This increases the risk of injury.

• Do not pull yourself up onto the trampoline by the padded edge.

• Do not use the trampoline if it is wet. The trampoline pad becomes slippery and this increases the risk of the jumper falling and injuring him/herself.

• Do not use the trampoline in strong winds. This may unbalance the jumper and thereby result in serious injuries.

• Inspect the trampoline for defects before use EVERY time.

• Tighten up fittings and check regularly that all ties have been tied correctly.

• Replace any worn or defective parts. Remedy any defects. Make sure that the trampoline is free of algae, soil, etc.

• Do not use shoes, boots or other footwear on the trampoline.

• Make sure that pockets are empty when using the trampoline. Make sure that clothes and pockets do not contain sharp objects when using the trampoline.

• Do not allow pets onto the trampoline. Sharp claws can damage the trampoline pad.

• If using a ladder to get on and off the trampoline, please make sure that the trampoline is not used without supervision! remove the ladder, if appli-cable.

• Do not use the trampoline after dark.

• Make sure the zip on the netting remains closed when the trampoline is in use. Remember that the netting is not designed for jumping into to gain more speed or for taking off faster!

• Make sure that the hook-and-loop fasteners are closed correctly during use of trampoline.

• Check regularly that the netting has been fitted correctly.

Tighten up the assembly fittings.

• Inspect the trampoline and the netting for defects before use EVERY time. Tighten up fittings and check regularly that all ties have been tied correctly.

• Before season is started maintenance is required.

• Regular maintenance is required. Neglecting regular maintenance can lead to a risk

for users.

• Check all nuts and bolts for tightness and tighten when required.

• Check that all spring-loaded (pit pin) joints are still intact and cannot become dislodged during play.

• Only one user at a time due to collision hazard.

• No Somersaults are allowed.

• Adult supervision required.

• Check all coverings for bolts and sharp edges and replace when required.

• Modifications made by consumer to the original trampoline (e.g. the adding of an accessory) Shall be carried out according to the instructions of the manufacturer.

**Location of the trampoline:**

• There must be a minimum headroom above the trampoline of 7.3 metres, i.e. this area should be free of objects of any kind.

• The trampoline must be placed on a flat and level surface.

• The surface must not be concrete, tiles or asphalt.

• No objects must be placed under the trampoline.

• The trampoline must be located at a suitable distance (minimum 2.5 m) from electric cables, swimming pools, fences, trees and branches, climbing frames and other objects.

• The trampoline must be located at a suitable distance (minimum 2.5 m) from electric cables, swimming pools, fences, trees and branches, climbing frames and other objects.

**Maintenance:**



Clean the trampoline pad using a damp cloth to remove any algae, dirt, etc. Then wipe with a dry cloth. Do not use the trampoline before it is completely dry. Do not use cleaning agents or other chemicals to clean the product. Tighten all fittings regularly, and make sure the mat is correctly fitted.

**Further information**


We recommend securing the trampoline in strong winds. Tie the trampoline down with ropes attached to the trampoline pad. Tie the trampoline down in a minimum of three places distributed evenly across the trampoline frame. Do not secure the legs as these may become misaligned and ruin the trampoline. Dismantle or remove the trampoline completely, if required. It may result in great danger if the trampoline is not secured in strong winds.

**WARNING:**


- Safety net needs to be replaced after 2 years.
- Before jumping you need to close safety net.
- Forbidden to eat during jumping.
- The trampoline is not intended to be dug into the ground.
- In certain countries during winter, the snow load and very low temperature can damage the trampoline. It is recommended to remove the snow, and store the mat and enclosure indoor.




1




2




3




1




2













3





4






4




5



6




1




x 6

2




x 6

3




x 6

4




x 6

5




x 1

6




x 1

7




x 1

8



x 2

9





x 6

10










x 1

7





8





1

2



**GB IMPORTANT INFORMATION.**

The trampoline and net should be packed away during the winter. Make sure that all parts are dry and packed safely. Store in a dry place. Please be aware that wind and weather may cause deterioration.