

**HOMEBASE**

# ANDORRA 2 SEATER SWING SET

Powder-coated steel frame  
H159 x W117 x D156.5cm



## INSTRUCTION MANUAL

IMPORTANT: Please read these instructions before using the product and retain for future use.

HHGL Limited, MK9 1BA; HHGL (ROI) Limited, D02 X576

## SAFETY & CARE ADVICE

Please read these instructions fully before starting assembly.

- Check you have all the components listed on page 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area; small parts could pose a choking hazard if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the component parts or the product, as this could cause damage.
- Assemble the item as close to its final position as possible.
- Assemble on a soft, level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with two people.
- We do not recommend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.
- Domestic use only.
- Maximum user weight is 110kg per seat.
- We recommend that you cover your garden furniture when it's not in use and that it is stored in a garage or shed throughout the winter months. Please ensure the furniture is dry before storing.














## IMPORTANT INFORMATION

- Regularly check all the bolts, screws and fastenings are secure.
- Only clean using a damp cloth and mild detergent; do not use bleach or abrasive cleaners.
- This product should not be discarded with household waste. Take it to your local authority waste disposal centre.

## COMPONENTS

Please check you have all components listed below. If you have any missing or damaged components, please contact your local store.








1		x 1
2		x 2
3		x 2
4		x 2
5		x 1
6		x 4







7		x 1
8		x 1
9		x 2
10		x 1
11		x 1

## COMPONENTS - FITTINGS

Please check you have all fittings listed below. If you have any missing or damaged fittings, please contact your local store.

**Note:** The quantities below are the correct amount to complete the assembly. In some cases, more fittings may be supplied than required.

A		x 4
B		x 4
C		x 8
D		x 6
E		x 36
F		x 4
G		x 14


H		x 2
I		x 2
J		x 2
K		x 4
L		x 1
M		x 1

# ASSEMBLY INSTRUCTIONS

**NOTE:** When fastening with nuts and bolts, always use a washer (E) between the tube and the bolt or the tube and the nut.


## Step 1

Fasten the front and rear upright supports (2 and 3) at the top by using bolts (A), washers (E) and metal nuts (G). Repeat the same procedure for both sides. Keep the bolts loose. At both ends, insert the assembled upright supports (2 and 3) into the top cross beam (1).




## Step 2

Fasten the lateral cross braces (4) to the upright supports (2 and 3) by using bolts (B), washers (E) and metal nuts (G). Repeat the same procedure for both sides. Fasten the rear cross brace (5) to the rear upright supports (3) by using bolts (B), washers (E) and metal nuts (G). Insert the leg caps (K) into all of the base feet. Tighten all of the nuts and bolts.




### Step 3

Insert the arm connecting tube (9) to the swing arm (7 and 8).




### Step 4

Fasten the arm connecting tube (9) to the seat assembly (10) by using bolts (C), washers (E) and metal nuts (G). Repeat the same procedure for both sides.



### Step 4

Fasten a swing arm tube (6) and a swing arm (7) to the seat back by using bolt (D), washers (E) and metal nuts (G). Repeat the same procedure for both sides. Fasten another swing arm tube (6) to the swing arm (8) at the front bend by using bolt (D), washers (E) and metal nuts (G). Repeat the same procedure for both sides.




### Step 5

Hook the suspension springs (H) into the top of both swing arm tubes (6). Do the same procedure for both sides. Hang the opposite ends of the suspension springs (H) into the holes located on the angled braces of the top cross beam (1). Repeat the same procedure for both sides.

### Warning:

Make sure that both ends of the suspension springs (H) go completely through the holes on the top cross beam (1) and the swing arm tubes (6).




) to each side of canopy/frame connectors (J).

### Step 6

Slide the canopy/frame connectors (J) into the canopy (11). Fasten them together by using screws (F) in the pre-drilled holes. Make sure that the teeth of the canopy/frame connectors are facing towards the inside of the frame. Attach and fasten the Canopy assembly onto the adjustable teeth on top of the cross beam (1) with plastic screws (I) to each side of the canopy/frame connectors (J).

### Warning:

To assure stability, double check that all of the bolts have been completely tightened.



**ASSEMBLY COMPLETE**